Quality and reliability is our tradition.



Lighting level is shown by **digital display** It is possible to measure illuminance from 0.1 to 19990 lux.



Digital light meter with separate light receiving sensor and meter.

Specifications

Model	Model 5202				
Ranges	0.1~19990Lux				
Accuracy (23℃±5℃)	Lux	Accuracy	Fc	Accuracy	
	200	\pm (4% rdg+5 rdg)	20	\pm (4% rdg+5 rdg)	
	2000	\pm (4% rdg+5 rdg)	200	\pm (4% rdg+5 rdg)	
	20000	\pm (5% rdg+4 rdg)	2000	\pm (5% rdg+4 rdg)	
Current Consumption	2mA approx				
Response Time	2.5times / sec.				
Operating Temperature Range	0~50°C Below 80% RH				
Storage Temperature Range	-10°C~60°C				
Augular Incident light characteristics	30° Less than $\pm 3\%$				
	60° Less than $\pm 10\%$				
	80°Less than $\pm 30\%$				
Spectral response characteristics	JIS C1609 CLASS A				
Power source	6F22(9V)				
Dimensions	Meter:148(L)×71(W)×36(H)mm				
	Light receiving sensor: $85(L) \times 67(W) \times 32(H)$ mm				
Weight	270g				
Accessories	Ca	rrying Case \times 1	Pho	tocall Cover \times 1	
	($6F22(9V) \times 1$	Instru	uction Manual \times 1	

INSTRUMENT LAYOUT

1.Display window 3.Data hold switch 7.Sensor Cover

2. Power Switch 4.Range Switch 5.Off set adjustment 6.Light receiving sensor



DIGITAL ILLUMINOMETER

MODEL5

1	Features	Specifications		
J 1	Model 5201 is a highly portable and compact digi- tal illuminance from 0.1	MODEL		
		Ranges	0.1~19990Lux(automatic 3 range switching	
to 19,990 Lux, with auto	Accuracy	±5%rdg±3dgt		
	range switching. •The digital display is held for a preset time(about 20 seconds)and,therefore, facilitates reading, record- ing and measuring in any direction.	Measuring Time	3 times per second	
		Temperature humidity characteristics	±3%(at 20℃)	
		Augular Incident	Closely related to the Lambert's cosine law	
13		Light Characteristics		
		Spectral Response	Closely related to the spectral	
-10		Characteristics	luminous efflciency (of a standard observer)	
34/1		Power Source	6F22(9V)×1	
		Dimensions	166(L)×68(W)×32(D)mm	
		Weight	180g approx	
		Accessories	Photocell Cover 6F22×1 Soft Carrying Case Instruction Manual	



Please read the "Safety Warnings" in the instruction manual supplied with the instrument thoroughly and completely for correct use. Failure to follow the safety rules can cause fire, trouble, electrical shock, etc. Therefore, make sure to operate the instrument on a correct power supply and voltage rating marked on each instrument.

%The contents of this catalogue may be subject to change without notice.

DISTRIBUTOR



KYORITSU ELECTRICAL INSTRUMENTS WORKS, LTD.

No. 5-20 Nakane 2-chome, Meguro-Ku, Tokyo, 152-0031 Japan Phone:81-3-3723-0131 Fax:81-3-3723-0152 URL:http://www.kew-ltd.co.jp E-mail:info@kew-ltd.co.jp Factories: Uwajima & Ehime